

NFPA 72 AND ADA DEVICE INSTALLATION REQUIREMENTS



FIRE ALARM DEVICE MOUNTING DETAIL SCALE: N.T.S.



FIRE ALARM RISER DIAGRAM (BASE BID) SCALE: 3/32" = 1'-0"

FIRE ALARM ALT BID: COST TO PROVIDE AND INSTALL ALL LABOR, MATERIAL, EQUIPMENT AND PROGRAMMING TO REMOVE THE EXISTING FIRE ALARM SYSTEM, INSTALL NEW DEVICES TO REPLACE THE EXISTING AND TIE EVERYTHING BACK TO THE NEW FACP IN THE GYM ADDITION. (SEE FA101)

WIRE LEGEND A 1 PAIR #16 SHIELDED CABLE B 2 COND. #14 THHN C 4 COND. #14 THHN D 8 COND. #22 E 2 PAIR #18 SHIELDED + 2 COND. # 14 THHN

WALL LEGEND % NON−RATED WALL SMOKE TIGHT CONSTRUCTION WALLS AND CEILING ONE HOUR RATED FIRE BARRIER TWO HOUR RATED FIRE BARRIER

(SEE MOUNTING HEIGHT SCHEDULE FOR MOUNTING INFORMATION UNLESS NOTED OTHERWISE) FIRE ALARM MANUAL PULL STATION

FIRE ALARM HORN/STROBE VOICE NOTIFICATION FIRE ALARM/STROBE

SP VOICE NOTIFICATION SPEAKER

FIRE ALARM STROBE S SMOKE DETECTOR

HEAT DETECTOR, CEILING MOUNTED FACP FIRE ALARM CONTROL PANEL, FLUSH MOUNTED.

RA REMOTE ANNUNICATOR PANEL, FLUSH MOUNTED

DUCT MOUNTED SMOKE DETECTOR, PROVIDED AND WIRED BY E.C., INSTALLED BY M.C.

R SHUT DOWN RELAY PROVIDED AND AND WIRED BY E.C.

DUCT MOUNTED SMOKE DETECTOR REMOTE INDICATOR LIGHT MOUNTED IN CEILING PROVIDED AND INSTALLED BY E.C., LABEL ACCORDING TO MECHANICAL UNIT SERVED.

FSPRINKLER RISER WATER FLOW SENSOR. PROVIDED & WIRED BY E.C., INSTALLED BY SPRINKLER CONTRACTOR.

SPRINKLER RISER TAMPER SWITCH. PROVIDED AND WIRED BY E.C. INSTALLED BY SPRINKLER CONTRACTOR.

SPRINKLER RISER WATER VALVE SHUT-OFF SENSOR. PROVIDED & WIRED BY E.C., INSTALLED BY SPRINKLER CONTRACTOR.


AREA OF RESCUE ASSISTANCE BASE STATION WITH VISUAL LOCATION INDICATOR. RATH 2500-205FMC (OR EQUAL)


AREA OF RESCUE ASSISTANCE 2—WAY COMMUNICATION REMOTE STATION. RATH 2100 FLUSH MTD (OR EQUAL)

MAGNETIC DOOR HOLD OPEN DEVICE (POE)

CARBON MON-OXIDE SENSOR

FIRE ALARM SYSTEM ACTION MATRIX		SYSTEM ACTION																						
	ACTUATE COMMON ALARM SIGNAL INDICATOR	ACTUATE AUDIBLE ALARM SIGNAL	ACTUATE AUDIBLE LOCAL ALARM SIGNAL	ACTUATE VOICE NOTIFICATION	ACTUATE COMMON SUPERVISORY SIGNAL INDICATOR	ACTUATE AUDIBLE SUPERVISORY SIGNAL	ACTUATE COMMON TROUBLE SIGNAL INDICATOR	ACTUATE AUDIBLE TROUBLE SIGNAL	ACTUATE APPROPRIATE LOCATION INDICATOR	ACTUATE ALL AUDIBLE EVACUATION SIGNALS	ACTUATE ALL VISIBLE EVACUATION SIGNALS	DISPLAY / PRINT CHANGE OF STATUS	TRANSMIT ALARM SIGNAL TO SUPERVISING STATION	TRANSMIT SUPERVISORY SIGNAL TO SUPERVISING STATION	TRANSMIT TROUBLE SIGNAL TO SUPERVISING STATION	FAN SHUT DOWN (SPECIFIC UNITS WING)	FAN SHUT DOWN (UNIVERSAL)	SHUNT POWER TO ELEVATOR	DAMPER SHUT DOWN	RELEASE MAGNETIC DOORS	FIRE SHUTTERS	SHUNT ALL GAS & POWER UNDER HOOD	COMMENTS/REM	IARKS
MANUAL ALARM STATION	Х	X		Х					Х	X	Х	Х	Х				Х		Х	X	Х		ALARM IN NEW DISPATCH TO G	BLDG ONLY AN
SMOKE SENSOR / DETECTOR	Х	X		X					X	X	X	X	X				X		X	X	X			
DUCT SENSOR / DETECTOR					X	Х			X	X	X	Х	X			Х								
WATERFLOW SWITCH	Х	X		Х					Х	X	Х	Х	Х				Х	Х	Х	Х	Х			
TAMPER SWITCH					X	Х			Х			Х		X										
EMERGENCY LOCKDOWN BUTTON																				Х				
CARBON MON-OXIDE SENSOR			X		X	Х			X			Х		X										<u> </u>
FIRE ALARM AC POWER FAILURE							X	X				X			X									1
FIRE ALARM SYSTEM LOW BATTERY							X	X				X			X									
OPEN CIRCUIT							X	X				X			X									
GROUND FAULT							X	X				X			X									
NOTIFICATION APPLIANCE CIRCUIT WIRE-TO-WIRE SHORT							X	X				X												
MANUAL ALARM STATION	Х	Х		Х					Х	Х	Х	Х	Х				Х		Х	Х	Х		ALARM IN EXIST DISPATCH TO EX	T BLDG ONLY A
SMOKE SENSOR / DETECTOR	Х	X		X					X	Х	Х	X	X				Х		X	Х	X			
DUCT SENSOR / DETECTOR					X	Х			Х	X	X	Х	X			X								,
MONITORING STAION																								





4

A